SIEMENS

SIMATIC NET

Introduction to PROFIBUS on Industrial PC

Volume 1 of 1

- 1 The Product Spectrum Around the CP 5412 (A2)
- 2 How to Use the Manuals
- 3 Description of the Architecture
- 4 Addresses for Help and Training
- 5 Further Reading

Glossary

C79000-G8976-C068

Release 05

SIEMENS

Wir haben den Inhalt der Druckschrift auf Übereinstimmung mit der beschriebenen Hard- und Software geprüft. Dennoch können Abweichungen nicht ausgeschlossen werden, so daß wir für die vollständige Übereinstimmung keine Gewähr übernehmen. Die Angaben in der Druckschrift werden jedoch regelmäßig überprüft. Notwendige Korrekturen sind in den nachfolgenden Auflagen enthalten. Für Verbesserungsvorschläge sind wir dankbar.

Technische Änderungen vorbehalten. Weitergabe sowie Vervielfältigung dieser Unterlage, Verwertung und Mitteilung ihres Inhalts nicht gestattet, soweit nicht ausdrücklich zugestanden. Zuwiderhandlungen verpflichten zu Schadenersatz. Alle Rechte vorbehalten, insbesondere für den Fall der Patenterteilung oder GM-Eintragung.

C79000-G8976-C068 Copyright © Siemens AG 1996 All Rights Reserved

We have checked the contents of this manual for agreement with the hardware described. Since deviations cannot be precluded entirely, we cannot guarantee full agreement. However, the data in this manual are reviewed regularly and any necessary corrections included in subsequent editions. Suggestions for improvement are welcome.

Technical data subject to change.

The reproduction, transmission or use of this document or its contents is not permitted without express written authority. Offenders will be liable for damages. All rights, including rights created by patent grant or registration of a utility or design, are reserved.

C79000-G8976-C068 Copyright © Siemens AG 1996 All Rights Reserved

Nous avons vérifié la conformité du contenu du présent manuel avec le matériel et le logiciel qui y sont décrits. Or, des divergences n'étant pas exclues, nous ne pouvons pas nous porter garants pour la conformité intégrale. Si l'usage du manuel devait révéler des erreurs, nous en tiendrons compte et apporterons les corrections nécessaires dès la prochaine édition. Veuillez nous faire part de vos suggestions.

Nous nous réservons le droit de modifier les caractéristiques techniques.

Toute communication ou reproduction de ce support d'informations, toute exploitation ou communication de son contenu sont interdites, sauf autorisation expresse. Tout manquement à cette règle est illicite et expose son auteur au versement de dommages et intérêts. Tous nos droits sont réservés, notamment pour le cas de la délivrance d'un brevet ou celui de l'enregistrement d'un modèle d'utilité.

C79000-G8976-C068 Copyright © Siemens AG 1996 All Rights Reserved

SIEMENS

SIMATIC NET

Introduction to PROFIBUS on Industrial PC

Description C79000-B8976-C068/05

Note

We would point out that the contents of this product documentation shall not become a part of or modify any prior or existing agreement, commitment or legal relationship. The Purchase Agreement contains the complete and exclusive obligations of Siemens. Any statements contained in this documentation do not create new warranties or restrict the existing warranty.

We would further point out that, for reasons of clarity, these operating instructions cannot deal with every possible problem arising from the use of this device. Should you require further information or if any special problems arise which are not sufficiently dealt with in the operating instructions, please contact your local Siemens representative.

General

This device is electrically operated. In operation, certain parts of this device carry a dangerously high voltage.

WARNING!



Failure to heed warnings may result in serious physical injury and/or material damage.

Only appropriately qualified personnel may operate this equipment or work in its vicinity. Personnel must be thoroughly familiar with all warnings and maintenance measures in accordance with these operating instructions.

Correct and safe operation of this equipment requires proper transport, storage and assembly as well as careful operator control and maintenance.

Personnel qualification requirements

Qualified personnel as referred to in the operating instructions or in the warning notes are defined as persons who are familiar with the installation, assembly, startup and operation of this product and who posses the relevant qualifications for their work, e.g.:

- Training in or authorization for connecting up, grounding or labelling circuits and devices or systems in accordance with current standards in safety technology;
- Training in or authorization for the maintenance and use of suitable safety equipment in accordance with current standards in safety technology;
- First Aid qualification.

Manuals for PROFIBUS on Industrial PC

Introduction to PROFIBUS on Industrial PC	
ET 200 Distributed I/O System	6ES5 998-3ES22
Configuring the S7 Mode with COML S7	
DP Programming Interface	
FDL Programming Interface	
FMS Programming Interface	
S7 Programming Interface	

Contents

1	The Product Spectrum Around the PROFIBUS on Industrial PC	
2	How to Use the Manuals	9
3	Description of the Architecture	
3.1	The ISO/OSI Reference Model	
3.2	SIMATIC NET Communications Networks	
3.3	PROFIBUS	
3.4	Network Architecture	
3.5	Overview of the Protocols	
	The PG Protocol	
	FMS Programming Interface	
	The DP Protocol	
	The FDL Protocol	
3.6	The Multiprotocol Mode	
3.7	Software and Hardware Components	
3.8	Communications Options	
	·	
4	Where to Obtain Help	
4.1	Help with Technical Questions Contacts for SIMATIC NET Training	
4.2	Contacts for SIMATIC NET Training	28
5	Further Reading	29
Glose	ary	21
01033	CALLY	

1 The Product Spectrum Around the PROFIBUS on Industrial PC

PROFIBUS CP

SIMATIC NET communications processors like the CP 5412 (A2) or CP 5511 form the hardware basis for attaching your personal computer (PC) or programming device (PG) to PROFIBUS.

Product Combinations

The following software products can only be used, if a PROFIBUS communications processor is installed in your PC or PG. Not every software package is available for all operating systems and all PROFIBUS communications processors. Further information about the possible combinations can be found in the SIMATIC NET catalog "IK 10" and the product information.

PG Package

With this software, you can operate the STEP 5 and STEP 7 program packages via PROFIBUS.

DP Package

With this software, you can develop and use application programs for the DP master on your PC or PG.

DP package contains the FDL programming interface, with which you can develop and use application programs for communication using layer 2 of PROFIBUS (for example, for communication with the SIMATIC S5-95).

FMS Package

With this software, you can develop and use application programs for FMS (layer 7 of PROFIBUS) on your PC or PG.

S7 Package

With this software, you can develop and use application programs for the S7 protocol (for data exchange with SIMATIC S7 systems) on your PC or PG.□

NOTES

2 How to Use the Manuals

Users of STEP 5 and STEP 7

Read

- the chapter Description of the Architecture,
- the Hardware Installation Instructions for your CP and
- the Software Installation Instructions for the PG package.

Users of DP Applications

Read

- the chapter Description of the Architecture,
- · the Hardware Installation Instructions for your CP,
- · the Software Installation Instructions for the DP package and
- the volume "ET 200 Distributed I/O System".

Programmers of DP Applications

Read

- the chapter Description of the Architecture,
- · the Hardware Installation Instructions for your CP,
- the Software Installation Instructions for the DP package,
- · the volume "The DP Programming Interface" and
- the volume "ET 200 Distributed I/O System".

Users of FDL Applications

Read

- the chapter Description of the Architecture,
- the Hardware Installation Instructions for your CP and
- the Software Installation Instructions for the DP package.

Programmers of FDL Applications

Read

- the chapter Description of the Architecture,
- · the Hardware Installation Instructions for your CP,
- the Software Installation Instructions for the DP package and
- the volume "FDL programming interface".

Users of FMS Applications

Read

- · the chapter Description of the Architecture,
- · the Hardware Installation Instructions for your CP,
- the Software Installation Instructions for the FMS package and
- the configuration instructions in the volume "ET 200 Distributed I/O System".

Programmers of FMS Applications

Read

- the chapter Description of the Architecture,
- the Hardware Installation Instructions for your CP,
- the Software Installation Instructions for the FMS package,
- the configuration instructions the volume "ET 200 Distributed I/O System" and
- · the volume "FMS Programming interface".

Users of S7 Applications

Read

- the chapter Description of the Architecture,
- the Hardware Installation Instructions for your CP,
- the Software Installation Instructions for the S7 package and
- the configuration instructions in the volume "Configuring the S7 Mode with COML S7".

Programmers of S7 Applications

Read

- the chapter Description of the Architecture,
- the Hardware Installation Instructions for your CP,
- the Software Installation Instructions for the S7 package and
- the configuration instructions in "Configuring the S7 Mode with COML S7" and
- the volume "S7 Programming Interface".

3 Description of the Architecture

This chapter provides you with an overview of the following:

- The conditions for trouble-free operation of a communications system.
- General information about the communications systems available from Siemens.
- Detailed information about the PROFIBUS communications network.

At the end of the chapter

- You will have the basic information you require about the reference model for communication, the ISO/OSI model.
- You will have an overview of the various communications networks available from Siemens for different applications and requirements.
- You will know the PROFIBUS architecture.

Above all, you will recognize the advantages of using PROFIBUS, such as:

- · Communication between all devices.
- Independence from specific vendors in a heterogeneous network.
- Applications based on standards allowing long-term planning and use of equipment and systems.

3.1 The ISO/OSI Reference Model

Trouble-Free Interaction

As the user of powerful automation components such as host computers, programmable logic controllers, printers, data servers etc., you expect trouble-free interaction between these devices and control systems and features such as:

- Use of communication systems without time-consuming configuration and programming.
- Independence from any one particular vendor.
- Flexible modification of plant structures without affecting communication.
- The highest possible reliability in data transmission.
- Long-term planning and use of equipment (today's devices should be able to communicate with those of tomorrow).

Open Communication

The answer to such requirements is a **heterogeneous network of automation components**, in which devices from a variety of vendors can communicate (**open communication**). In contrast, in a homogeneous network, only devices of one vendor can communicate with each other.

The ISO/OSI Reference Model

The International Standards Organization (ISO) defined a reference model for open system communication for heterogeneous networks. This ISO/OSI reference model provides a guideline for standardization of communications procedures. It provides a framework for standardizing communications procedures in seven layers. All manufacturers of automation components or generally of data terminal equipment, not only for industry, today base their products on the ISO/OSI reference model (Figure 3.1).

The Seven Layers of the ISO/OSI Model

	The Layers	and Their Tasks
7	Application layer	Provides uniform access to specific services.
6	Presentation layer	Establishes transfer syntax.
5	Session layer	Establishes, maintains, terminates communication sessions
4	Transport layer	Transfers "raw" information reliably.
3	Network layer	Provides network connections.
2	Data link layer	Establishes and terminates links.
1	Physical layer	Regulates physical connections for bit transfer.

Figure 3.1 The Seven Layers of the ISO/OSI Reference Model

3.2 SIMATIC NET Communications Networks

The Areas of Application of SIMATIC NET

SIMATIC NET is an open, heterogeneous communications system with a variety of local area networks (LANs) providing various ranges of performance for manufacturing and process automation in industry. It is based on national and international standards according to the ISO/OSI reference model.

SIMATIC NET Communications Networks

SIMATIC NET provides the following communications networks for different requirements (Figure 3.2):

- Industrial Ethernet, a cell and management level network based on IEEE 802.3 (ETHERNET).
- PROFIBUS, a cell and field level communications network complying with PROFIBUS (Process Field Bus, En 50 170. /1/
- AS-Interface (based on AS-i) a communications network for the actuator and sensor level.




Figure 3.2 SIMATIC NET Communications Networks

3.3 PROFIBUS

Area of Application of PROFIBUS

PROFIBUS is

- the network for the cell and field area of the medium performance range within the open, heterogeneous SIMATIC NET communications system intended primarily for an industrial environment.
- a powerful communications system for low-cost applications. It
 provides all the known advantages of a bus system and meets all
 the requirements for flexible, cost-effective networking of
 programmable logic controllers and computers in an industrial
 environment.

PROFIBUS

Known under the name PROFIBUS, PROFIBUS is based on the standard specified in EN 50 170 and is based on the ISO/OSI reference model. By meeting the requirements of EN 50 170, PROFIBUS provides the "openness" required for attaching components from other vendors that comply with the standard.

The Protocol Profile of PROFIBUS

PROFIBUS (Figure 3.3) is based on the ISO/OSI reference model, but does not implement all seven layers. For reasons of performance and to reduce costs, only layers 1 (Physical Layer / RS485) and 2 (Data Link Layer / FDL) for the physical bus characteristics and access techniques and layer 7 (Application Layer) as the user interface are implemented. The attachment of layer 7 to layer 2 is controlled by the lower layer interface (LLI). This provides all the required layer 3 to 6 functions.

Architecture of PROFIBUS




Figure 3.3 The PROFIBUS Architecture

3.4 Network Architecture

PC and PROFIBUS




Figure 3.4 Network Architecture of PROFIBUS

3.5 Overview of the Protocols

3.5.1 The PG Protocol

Area of Application of the PG Protocol

The PG protocol is used to operate the STEP 5 or STEP 7 SIMATIC software packages with SIMATIC NET communications processor.

This protocol allows access by STEP 5 or STEP 7 programs to SIMATIC programmable logic controllers via PROFIBUS.

The PG protocol is not yet available for the UNIX operating system.

3.5.2 FMS Programming Interface

SAPI-FMS

The Siemens implementation of the FMS programming interface is known as SAPI-FMS.

What Does SAPI-FMS Mean?

The acronym SAPI-FMS stands for:

- SAPI Simple Application Programmers Interface
- FMS Fieldbus Message Specification the layer 7 communications protocol of PROFIBUS.

What Is SAPI-FMS?

SAPI-FMS

- represents a simple C programming interface,
- provides access to the FMS services on PCs and PGs and
- is available as a C library and is operated with SIMATIC NET drivers and SIMATIC NET communications processors.

Advantages of the SAPI-FMS Programming Interface

The SAPI-FMS programming interface has the following advantages:

- SAPI-FMS is a simple but flexible and powerful interface.
- The SAPI-FMS programming interface uses asynchronous procedures.
- SAPI-FMS handles sequential services such as the transfer of a communication relationship list automatically.
- SAPI-FMS converts variable data automatically into the format of the local CPU.
- SAPI-FMS supports troubleshooting with an integrated trace function.
- The SAPI-FMS programming interface is compatible with other SAPI programming interfaces.
- The SAPI-FMS programming interface can also be used by other programs, for example BASIC or Pascal programs.

3.5.3 The DP Protocol

Distributed I/Os

The distributed peripheral I/Os (abbreviated to DP) allow you to use a large number of distributed analog and digital input/output modules in the immediate vicinity of the process.

Networking DP components using PROFIBUS means a considerable reduction in cabling compared with previous direct wiring of the components.

Large distances between the individual I/O devices can be bridged by PROFIBUS (PROFIBUS). Distributed I/O stations collect the input signals locally and these are then fetched by the central controller in the computer. The central controller also sends output data to the distributed I/O stations cyclically.

The DP protocol is intended for time-critical applications. An optimized and simplified transmission protocol means high transmission rates and the use of a master-slave structure results in short cycle times.

The DP protocol is based on the communications standard for the field area (PROFIBUS EN 50 170) EN 50 170. The concept of DP communication was worked out in a common project undertaken by leading manufacturers of automation equipment. It describes a heterogeneous transmission protocol tailor-made for the requirements of the field area.

Main Characteristics

The main characteristics of the distributed peripheral I/O system are as follows:

- · Central control by one master.
- High data throughput thanks to a simple transmission protocol.
- Cyclic transmission of the process image in the input and output direction.
- Simple, cost-effective network attachment.
- Data transmission with the option of twisted-pair (RS 485) or fiberoptic cables.
- Detection of errors with on-line diagnostics.
- Based on EN 50 170, allowing parallel operation with FMS devices (masters and slaves) on one bus.

The DP Interface of a PROFIBUS CP

Figure 3.5 shows the basic structure and the components of a PROFIBUS-DP system controlled by a computer with a PROFIBUS communications processor installed.




Figure 3.5 Basic Structure

Definition of DP Slave and DP Master

The PROFIBUS standard EN 50 170 defines two classes of station on the bus:

- Passive stations
- Active stations

In the distributed I/O system, the I/O devices are passive stations. They are known as **DP-Slaves**. The DP slaves are controlled by an active master station. This master station is known as the **DP master**.

DP Programming Interface

The DP programming interface allows the use of a PROFIBUS CP in a PG/PC as a DP master class 1. The PC in conjunction with the PROFIBUS CP controls communication with the distributed I/O devices and handles the central functions of a DP master class 1 according to EN 50 170. This involves the following functions:

- Initialization of the DP system.
- Parameter assignment/configuration of the DP slaves.
- · Cyclic data transfer to the DP slaves.
- · Monitoring the DP slaves.
- · Preparing diagnostic information.

3.5.4 S7 Programming Interface

SAPI-S7

SAPI-S7 is the C programming interface for access to the S7 communications protocol on PGs/PCs.

What Does SAPI-S7 Mean?

The acronym SAPI-FMS stands for:

- SAPI Simple Application Programmers Interface
- S7 layer 7 communications protocol for SIMATIC S7 systems.

What Is SAPI-S7?

SAPI-S7

- · Represents a simple C programming interface,
- Provides access to the S7 services on PCs and PGs and
- Is available as a C library and is operated with SIMATIC NET drivers and SIMATIC NET communications processors.

Advantages of the SAPI-S7 Programming Interface

The SAPI-S7 programming interface has the following advantages:

- SAPI-S7 is a simple but flexible and powerful interface.
- The SAPI-S7 programming interface uses asynchronous procedures.
- SAPI-S7 handles sequential services such as the active and passive establishment of an S7 connection.
- SAPI-S7 supports troubleshooting with an integrated trace function.
- The SAPI-S7 programming interface is compatible with other SAPI programming interfaces.
- The SAPI-S7 programming interface can also be used by other programs, for example BASIC or Pascal programs.

3.5.5 The FDL Protocol

Area of Application

of the

FDL Protocol

The FDL protocol is used for communication with PROFIBUS components complying with PROFIBUS EN 50 170. The CP can be operated as a master.

Services of the FDL Protocol

A distinction is made between management services and productive services. With the management services you can make the local settings required by the productive services. The productive services allow data transfer between the various PROFIBUS stations. A list of the services available can be found in the volume "FDL Programming Interface".

Creating an Application An application is created in the C/C++ programming language. The FDL application can be written for MS DOS, for MS Windows 3.x, for MS Windows 95, for MS Windows NT or for UNIX.

3.6 The Multiprotocol Mode

What does Multiprotocol Mode Mean? With multiprotocol mode you can process more than one protocol at the same time (for example DP and FMS). This applies both to the use of more than one protocol within an application as well as the parallel operation of more than one application with different protocols.

Support of Multiprotocol Mode

Support of multiprotocol mode may be restricted when using special communications processors and operating systems. You find further information in the product information.

3.7 Software and Hardware Components

The Software and Hardware Components under MS-DOS




Figure 3.6 Software and Hardware Components under MS DOS

The Software and Hardware Components under MS Windows 3.x, MS Windows 95, MS Windows NT




Figure 3.7 Software and Hardware Components under MS Windows 3.x, -95, -NT

The Software and Hardware Components under UNIX




Figure 3.8 Software and Hardware Components under UNIX

3.8 Communications Options

with SIMATIC S5

communication is possible using the following:

- the STEP 5 package
- · FMS applications
- · FDL applications
- DP applications

with SIMATIC S7

communication is possible using the following:

- STEP 7 package
- FMS applications
- S7 applications
- · FDL applications
- DP applications

with other PGs/PCs or workstations

communication is possible using the following:

- · FMS applications
- · FDL applications

with other programmable logic controllers

communication is possible using the following:

- · FMS applications
- · FDL applications
- · DP applications

with DP slaves

communication is possible using the following:

DP applications

SCOPE for PROFIBUS Diagnostic Tool

The SCOPE for PROFIBUS records all the frames and can be used to debug and troubleshoot when programming and installing systems. □

NOTES

4 Where to Obtain Help

4.1 Help with Technical Questions

Documentation

You will find information about topics related to using this software in the following sources:

- In the relevant printed documentation
- In the help system integrated in the software (F1 key)
- In text files on the SIMATIC NET CD

Who to Contact

If you have technical questions about using the software and your problem is not dealt with in the documentation or in the integrated help system, please contact your Siemens representative or dealer.

The addresses are listed in the following:

- in our Catalog IK 10
- on the Internet (http://www.ad.siemens.de/net)

Common Questions

Our customer support on the Internet provides useful information and answers to common questions. Under FAQ (Frequently Asked Questions), you will find a variety of information about our entire range of products.

The address of the SIMATIC NET homepage in the worldwide web of Internet is:

http://www.ad.siemens.de/net

Hotline

If you have problems, you can also contact our hotline:

• Telephone: 0911 - 895 - 7000

(from abroad +49 - 911 - 895 - 7000)

• Telefax: 0911 - 895 - 7002

(from abroad +49 - 911 - 895 - 7002)

E-Mail: simatic.support@nbgm.siemens.de

Mailbox (BBS, analog/ISDN, 8N1):

0911 - 895 - 7100

(vom Ausland +49 - 911 - 895 - 7100)

4.2 Contacts for SIMATIC NET Training

Course Enrollment

Siemens AG Trainings-Center für Automatisierungstechnik A&D PT41 Kursbüro

Östliche Rheinbrückenstraße 50 76181 Karlsruhe

Telephone 0721 - 595 - 2917
 from abroad +49 - 721 - 595 - 2917

• Fax 0721 - 595 - 6987 from abroad +49 - 721 - 595 - 6987

5 Further Reading

/1/ EN 50170, Volume 2 Deutsche elektrotechnische Komission im DIN und VDE (DKE), Frankfurt

NOTES

Glossary

Base address Logical address of a module in S7 systems.

Bus parameters
Bus parameters control the data transmission on the bus. Each ->

station on the -> PROFIBUS network must use bus parameters that

match those of other stations.

Bus segment Part of a -> subnet. Subnets can consist of bus segments and

connectivity devices such as repeaters and bridges. Segments are

transparent for addressing.

CFB Communication Function Block: A communication technique for

program-controlled transmission of data from or to a CPU in an S7-300/400 using special function blocks. These function blocks were defined based on the IEC 1131-5 draft. The communication partners can be other modules with communication capabilities in an S7-300/400, operator stations, PCs or other controllers and computers.

CP Communications Processor. Module for communication tasks.

Device master

data

Device master data (GSD) contain DP slave descriptions complying with EN 50 170, Volume 2. Using device master data makes

configuration of the -> DP master and -> DP slaves easier.

Distributed I/Os Input and output modules used at a distance (distributed) from the CPU

(central processing unit of the controller). The connection between the programmable controller and the distributed I/Os is established on -> PROFIBUS. The programmable logic controllers do not recognize any difference between these I/Os and local process inputs and outputs.

DP I/O module DP slaves have a modular design. A -> DP slave has at least one DP

I/O module.

DP I/O type The DP I/O type identifies a -> DP I/O module. The following types

exist:

Input module
Output module
Input/output module

DP master A -> station with master functions in -> PROFIBUS DP. The DP master

controls the exchange of user data with the -> DP slaves assigned to it.

DP module list The DP module list contains the modules belonging to a -> DP slave.

You make entries in the DP module list when configuring a -> DP

master with -> COM PROFIBUS.

DP module

name

Name of a -> DP I/O module entered in the -> DP module list.

DP module type Type identifier of a -> DP I/O module in the -> device master data of a

-> DP slave complying with EN 50 170, Volume 2.

DP slave A -> station with slave functions in -> PROFIBUS DP.

DP slave The DP slave catalog contains the device descriptions of -> DP slaves catalog

required for configuring -> DP masters according to the -> DP standard. The DP slave catalog is available when configuring with ->

COM PROFIBUS.

DP slave name A DP slave name is entered in the DP slave list to identify a -> DP

slave in the DP configuration.

DP subnet PROFIBUS subnet in which only -> distributed I/Os are operated.

DP subsystem A -> DP master and all -> DP slaves with which this DP master

exchanges data.

Driver Software required for the data transfer between applications and the ->

CP.

Enhanced mode Enhanced mode under 3.x for personal computers with an Intel 386 or

compatible processor.

FDL Fieldbus Data Link. Layer 2 in -> PROFIBUS.

Frame A message from one PROFIBUS station to another.

Frame header A frame header consists of an identifier for the -> frame and the source

and destination address.

Frame trailer A frame trailer consists of a checksum and the end identifier of the ->

frame.

FREEZE mode The FREEZE mode is a DP mode in which process data are acquired

> at the same time and fetched from all (or a group of) DP slaves. The time at which the data are acquired is indicated in the FREEZE

command (a synchronization control frame).

Gap update A free address area (gap) between two active -> stations is checked factor

cyclically by the station with the lower -> PROFIBUS address to find out whether or not another station is requesting to enter the logical ring.

The cycle time for this check is as follows:

gap update factor x target rotation time

Gateway Intelligent connectivity device that connects different types of local

area -> networks at OSI layer 7.

GD packet

Collection of data that may be distributed within the programmable logic controller (for example flags/memory bits or data blocks) to be transferred using the -> global data technique.

GD group

A GD group is a group of -> stations that exchange global data with each other. A -> GD packet is sent to the stations belonging to the GD group.

Global data

Global data (GD) is the name of a communication technique for the cyclic exchange of limited amounts of data from STEP 7 data areas between CPUs of the S7-300/400. Transmitted data can be received by several CPUs at the same time.

Global I/Os

Part of the I/O area of SIMATIC S5 PLCs can be used for global data exchange between SIMATIC S5 PLCs on -> PROFIBUS. The main characteristic of this technique is the cyclic transmission of data that have changed since the last cycle.

Group identifier

DP slaves can be assigned to one or more groups using a group identifier. The -> control frames can be addressed to specific groups of DP slaves using the group identifier.

Highest PROFIBUS address

A -> bus parameter for -> PROFIBUS. This specifies the highest -> PROFIBUS address (HSA) of an active -> station on the PROFIBUS bus. PROFIBUS addresses higher than the highest station address are possible for passive stations (possible values: HSA 1 to 126).

Master

An active station in -> PROFIBUS that can send -> frames on its own initiative when it is in possession of the token.

Maximum station delay

A -> bus parameter for -> PROFIBUS. The maximum station delay (max. TSDR) specifies the longest interval required by a -> station in the -> subnet between receiving the last bit of an unacknowledged -> frame and sending the first bit of the next frame. After sending an unacknowledged frame, a sender must wait for the max. TSDR to elapse before sending a further frame.

Minimum station delay

A -> bus parameter for -> PROFIBUS. The minimum station delay (min. TSDR) specifies the minimum time that the receiver of a -> frame must wait before sending the acknowledgment or sending a new frame. The min. TSDR takes into account the longest interval required by a station in the subnet for receiving an acknowledgment after sending a frame.

Network

A network consists of one or more interconnected -> subnets with any number of -> stations. Several networks can exist side by side. There is a common -> node table for every -> subnet.

Node table The node table applies to all -> networks within a -> system. Each

entry in the node table describes the interface between a programmable logic controller (or any other station) and a -> subnet. The entries in the subnet are used by the system to locate and

establish connections between stations.

Offset The length of the reserved area at the beginning of a data buffer of the

FDL programming interface.

Process image The process image is a special memory area in the programmable

> logic controller. At the start of the cyclic program, the signal states of the input modules are transferred to the process image of the inputs. At the end of the cyclic program, the process image of the outputs is

transferred to the output modules.

PROFIBUS SIMATIC NET bus system for industrial applications based on

PROFIBUS.

A fieldbus complying with EN 50 170.

The PROFIBUS address is a unique identifier for a -> station **PROFIBUS** address

connected to -> PROFIBUS (PROFIBUS). The PROFIBUS address is

transferred in the -> frame to address a -> station.

PROFIBUS DP PROFIBUS distributed I/Os. Transmission services complying with

PROFIBUS EN 50 170.

PROFIBUS DP A -> station with master functions in -> PROFIBUS DP.

PROFIBUS FMS PROFIBUS Fieldbus Message Specification. Upper sublayer of layer 7

of the ISO/OSI reference model for PROFIBUS.

PROFIBUS PA PROFIBUS PA is a recommendation of the PROFIBUS users'

organization extending PROFIBUS EN 50 170 to include aspects of

intrinsic safety.

Protocol A set of rules governing data transmission. Using these rules, both the

formats of the messages and the data flow during transmission can be

specified.

Reorganization

token ring

master

All the -> masters on -> PROFIBUS form a logical token ring. Within this token ring, the token is passed on from station to station. If the transmission of the token is incorrect or if a master is removed from the ring, this leads to an error when the token is passed on (the token is not accepted by this station) and the station is excluded from the ring.

SCOPE for PROFIBUS

Diagnostic software for -> PROFIBUS with which the traffic on the ->

network can be recorded and analyzed.

Segment Synonym for -> bus segment.

Services Services provided by a communication protocol.

Setup time A -> bus parameter for -> PROFIBUS. The setup time specifies the

minimum interval on the sender between receiving an acknowledgment

and sending a new call frame.

SIMATIC NET Siemens Network and Communication. Product name for -> Siemens

networks and network components.

Slot time A bus parameter for -> PROFIBUS. The slot time (TSL) is the time

during which the sender of a -> frame waits for the acknowledgment

from the receiver before detecting a timeout.

Station A station is identified by an -> PROFIBUS address in the ->

PROFIBUS network.

Subnet A subnet is part of a -> network whose -> bus parameters (for example

-> PROFIBUS addresses) must be matched. It includes the bus components and all attached stations. Subnets can, for example, be

connected together by -> gateways to form a network.

A -> system consists of several subnets with unique -> subnet

numbers. A subnet consists of several ->stations with unique ->

PROFIBUS addresses.

Subnet number A -> system consists of several -> subnets with unique subnet

numbers.

SYNC mode The SYNC mode is a DP mode in which several or all -> DP slaves

transfer data to their process outputs at a certain time. The time at which the data is transferred is indicated in the SYNC command (a

control command for synchronization).

System All the electrical equipment within a system. A system includes, among

other things, programmable logic controllers, devices for operation and

monitoring, bus systems, field devices, actuators, supply lines.

Target rotation

time

A -> bus parameter for -> PROFIBUS. The token represents the right to transmit for a -> station on PROFIBUS. A station compares the actual token rotation time it has measured with the target rotation time and depending on the result can then send high or low priority frames.

Transmission

rate

Transmission rate on the bus (unit in bits per second). A -> bus parameter for -> PROFIBUS. The set or selected transmission rate depends on various conditions, for example distance across the

network.

Watchdog (time)

A monitoring time that can be set for a -> DP slave so that it detects the failure of the -> DP master to which it is assigned.